

LED

LEDs meaning – EVO4S

Question:

How can I interpret my EVO4S LEDs behavior?

Answer:

Above, the possible EVO4S LEDs behaviors are described, specifying each one's meaning:

- Red LED, slow blinking (+ switched off display; if included):
 - It indicates the system has been started in Booter mode, not showing a normal behavior. In this case, it is suggested to update the device firmware, since it can be connected to the PC via USB.
- Green LED, fixed:
 - Indicates the system is correctly powered up.
- Red LED, slow blinking -> Red LED, fast blinking -> device reboot:
 - this behavior indicates the good result of the firmware upgrade process (together with a displayed popup message, if present).
- Blue LED, fast blinking:
 - Indicates the overwriting of the transmitted configuration.
- Cyan LED; fixed:
 - Indicates the system is recording data.